

Pinnacle Operating Instructions

- Press Mode button to turn on
- Top (3) **blue** lights show signal present (Video/Audio/Audio)
- Press Mode button to select (3) **blue** lights under button
- Insert USB drive
- When light above drive turns **blue**, you are ready to record
- Press Rec button solidly – but less than 2 seconds
- *If **blue** lights below Mode start cycling, you have pressed Rec twice and will have to wait 30 seconds to begin again. See Below*
- Unit will go into record – USB drive light should turn **RED**
- Press Rec button to stop recording
- When light above USB drive turns **blue**, you may remove drive
- Minimum record time is 30 seconds – if you press record button to stop recording before 30 seconds, unit will lock you out until it finishes that 30 second recording. Blue lights below Mode will begin cycling during this time. When **RED** light above USB drive turns **blue**, you can then start new recording.